



BITE GEL™

THEATRICAL TEETH MOLDING ALGINATE

Description: New from the creator of Monster Clay©, **BITE GEL™** is our brand new Tooth Grade Impression Alginate. Formulated for teeth models, **BITE GEL™** picks up phenomenal detail and can also be used for small area lifecasting jobs. Effortlessly cast models in stone, plaster, fast cast urethane, acrylic and wax without a mold release. Made with all natural non-toxic food grade products, **BITE GEL™** is the safe way to replicate your teeth. Crystalline Silica Free.

PRODUCT FEATURES

Mixing Instructions and Proportions

(Starting point ratio can be adjusted to your needs)

Mix 2 parts Bite Gel™ to 1 part water by volume.

-Stir water into Bite Gel™ (80°F/26°C water is Recommended)

-Mix until smooth (about 30-45 seconds)

-Transfer into impression tray

-Bite Gel™ will set in 1.5 to 2 minutes.

-Pour stone into the bite mold as soon as possible.

Helpful Tips:

-Colder water will slow the setting time.

-Alternatively, warmer water will speed it up.

-Adding excess water will make the mixture thinner and may soften the setting strength.

-Bite Gel™ will not stick to itself after it is set.

-Do not soak the mold in water as the alginate can swell and reduce accuracy.

The safety data sheet (SDS) for this or any Monster Makers product should be read before using and is available on request. All Monster Makers products are safe to use if directions are read and followed carefully. **Keep Out of Reach of Children.**

For more information, please visit www.monstermakers.com

©2018 The Monster Makers, Inc. All Rights Reserved